



# Quick Sheet Instructions

## Slat Installation Instructions

VAL-CO™ P/N 630000, 465011, 465012, 465050

U:\MANUALS\990000\990030 rev 2  
DKA 4-18-2011

- **INSTALLATION INSTRUCTIONS**

- The core temperature of the slats must be at least 40°F (5°C) when they are installed (i.e. they must be stored in a location prior to installation that is at least 40°F (5°C) for approximately 24 hours).
- During installation the house temperature must remain above 40°F (5°C).
- The slats are made of polypropylene, thus they will expand and contract as the temperature changes. Make sure you take this into account as you install your slats/substructure.

### **WARNING**

- Poultry flooring is designed to support the weight of chickens. Workers must walk only on supported areas of the flooring.
- Care must be taken to prevent impact loading of the flooring slats. Impact loading includes the dropping of objects and bouncing of personnel weight.
- If a hard object >10 lbs (4.5 kg) is dropped onto a slat the slat must be replaced (internal damage may have occurred which may or may not be visible)
- Any broken slats must be replaced immediately

---

#### North America:

Phone: 800.99VALCO  
(800.998.2526) Fax: 419.678.2200  
Email: sales@valcompanies.com



#### International:

Phone: 419.678.8731  
Fax: 419.678.2200  
Email: intl.sales@valcompanies.com