

ASSEMBLY INSTRUCTIONS:

- 1. JOIN THE HANDLE AND HANDLE EXTENSION TOGETHER BY SLIDING THE SQUARE END OF THE HANDLE INTO THE COUPLING ON THE HANDLE EXTENSION
 2. FOR FLOOR WATERING LINES: SCREW THE THREADED END OF THE HANDLE INTO THE TOP OF THE COLLECTOR ASSEMBLY AND HAND TIGHTEN
 3. FOR CAGE WATERING LINES: SCREW THE THREADED END OF THE HANDLE INTO
- THE BACK OF THE COLLECTOR ASSEMBLY AND HAND TIGHTEN

UNSPECIFIED TOLERANCES DECIMAL 2 PLACE ± .063 3 PLACE ± .031 4 PLACE ± .015 ANGULAR ± 1/2°	DIMENSIONS IN [] ARE MILLIMETERS UNLESS OTHERWISE		VALCO COMPANIES, INC.	•
	SPECIFIED. DO NOT SCALE	VALCO	PO BOX 8 NEW HOLLAND, PA 17557	
This drawing and any print there of is the property of VALCO COMPANIES INC, and is subject to return on request by this company. The information shown is confidential and the recipient by accepting this drawing agrees not to use any information contained thereon in any manner which will be detrimental to VALCO COMPANIES INC.	DATE 2/1/2013	NAME		
	drawn DBT	INSTALLATION INSTRUCTIONS, VAL-LOTT-STICK		
	CHECK			
	WEIGHT	SHEET 1 OF 1	990079	REV
	SCALE 1:8			Α