




Burn Mizer™ Cremator

Oil Burner - Repair Parts List




KEY #	PART #	DESCRIPTION	QTY
1	4751213	Gun Assembly	1
2	4751205	120 VAC 60 HZ Transformer	1
2	4751252	230 VAC 50 HZ Transformer	1
2	4751252-60	230 VAC 60 HZ Transformer	1
3	4751243	Digital Control With Terminal Strip	1
3	475339	Electronic Control	1
4	4751201	120 VAC 60 HZ Motor	1
4	4751251	230 VAC 50 HZ or 60 HZ Motor	1
5	4751203	Fan	1
6	4751204	Housing	1
7	4751207	Inner Air Band	1
8	4751209	Drive Coupler	1
9	4751211	Fuel Pump 60 HZ	1
9	4751253	Fuel Pump 50 HZ	1
10	4751237	Fuel Valve 120 VAC	1
10	4751254	Fuel Valve 230VAC	1
11	4751210	Oil Line Assembly	1
12	4751208	Outer Air Band	1
13	4751235	Slot Cover Plate	1
14	4751230	Air Tube Assembly	1
15	4751216	Gasket	1

Oil Burner - Replacement Parts List

PART #	DESCRIPTION		QTY
475300	BURNER, CREMATOR, MECH CTRL	OIL, 120V, 60HZ, MODEL 12	1
475301	BURNER, CREMATOR, MECH CTRL	OIL, 220V, 50HZ, MODEL 12	1
475302	BURNER, CREMATOR, MECH CTRL	OIL, 220V, 60HZ, MODEL 12	1
475303	BURNER, CREMATOR, MECH CTRL	OIL, 120V, 60HZ, MODEL 20	1
475304	BURNER, CREMATOR, MECH CTRL	OIL, 220V, 50HZ, MODEL 20	1
475305	BURNER, CREMATOR, MECH CTRL	OIL, 220V, 60HZ, MODEL 20	1
475306	BURNER, CREMATOR, MECH CTRL	OIL, 120V, 60HZ, MODEL 4820	1
475307	BURNER, CREMATOR, MECH CTRL	OIL, 220V, 50HZ, MODEL 4820	1
475308	BURNER, CREMATOR, MECH CTRL	OIL, 220V, 60HZ, MODEL 4820	1
475309	BURNER, CREMATOR, ELEC CTRL	OIL, 120V, 60HZ, MODEL 4830	1
475310	BURNER, CREMATOR, ELEC CTRL	OIL, 220V, 50HZ, MODEL 4830	1
475311	BURNER, CREMATOR, ELEC CTRL	OIL, 220V, 60HZ, MODEL 4830	1
475312	BURNER, CREMATOR, NO CTRL	OIL, 120V, 60HZ, MODEL 4830	1
475313	BURNER, CREMATOR, NO CTRL	OIL, 220V, 50HZ, MODEL 4830	1
475314	BURNER, CREMATOR, NO CTRL	OIL, 220V, 60HZ, MODEL 4830	1
475315	BURNER, CREMATOR, ELEC CTRL	OIL, 120V, 60HZ, MDL 7230/8430	1
475316	BURNER, CREMATOR, ELEC CTRL	OIL, 220V, 50HZ, MDL 7230/8430	1
475317	BURNER, CREMATOR, ELEC CTRL	OIL, 220V, 60HZ, MDL 7230/8430	1
475318	BURNER, CREMATOR, NO CTRL	OIL, 120V, 60HZ, MODEL 7230/8430	1
475319	BURNER, CREMATOR, NO CTRL	OIL, 220V, 50HZ, MODEL 7230/8430	1
475320	BURNER, CREMATOR, NO CTRL	OIL, 220V, 60HZ, MODEL 7230/8430	1
475321	BURNER, CREMATOR, ELEC CTRL	OIL, 120V, 60HZ, MODEL 8436	1
475322	BURNER, CREMATOR, ELEC CTRL	OIL, 220V, 50HZ, MODEL 8436	1
475323	BURNER, CREMATOR, ELEC CTRL	OIL, 220V, 60HZ, MODEL 8436	1
475324	BURNER, CREMATOR, NO CTRL	OIL, 120V, 60HZ, MODEL 8436	1
475325	BURNER, CREMATOR, NO CTRL	OIL, 220V, 50HZ, MODEL 8436	1
475326	BURNER, CREMATOR, NO CTRL	OIL, 220V, 60HZ, MODEL 8436	1
475327	BURNER, CREMATOR, ELEC CTRL	OIL, 120V, 60HZ, MODEL 9642	1
475328	BURNER, CREMATOR, ELEC CTRL	OIL, 220V, 50HZ, MODEL 9642	1
475329	BURNER, CREMATOR, ELEC CTRL	OIL, 220V, 60HZ, MODEL 9642	1
475330	BURNER, CREMATOR, NO CTRL	OIL, 120V, 60HZ, MODEL 9642	1
475331	BURNER, CREMATOR, NO CTRL	OIL, 220V, 50HZ, MODEL 9642	1
475332	BURNER, CREMATOR, NO CTRL	OIL, 220V, 60HZ, MODEL 9642	1
475333	BURNER, CREMATOR, ELEC CTRL	OIL, 120V, 60HZ, MODEL 10852	1
475334	BURNER, CREMATOR, ELEC CTRL	OIL, 220V, 50HZ, MODEL 10852	1
475335	BURNER, CREMATOR, ELEC CTRL	OIL, 220V, 60HZ, MODEL 10852	1
475336	BURNER, CREMATOR, NO CTRL	OIL, 120V, 60HZ, MODEL 10852	1
475337	BURNER, CREMATOR, NO CTRL	OIL, 220V, 50HZ, MODEL 10852	1
475338	BURNER, CREMATOR, NO CTRL	OIL, 220V, 60HZ, MODEL 10852	1

Oil Burner - Gun Assembly (4751213) Replacement Parts List



KEY #	PART #	DESCRIPTION	QTY
1	4751001	1.20 GPH Nozzle, Model 20	1
1	4751002	1.35 GPH Nozzle, Model 4820/4830	1
1	4751005	1.10 GPH Nozzle, Model 12	1
1	4751006	2.25 GPH Nozzle, Model 9642/10852	1
1	4751007	2.00 GPH Nozzle, Model 8436	1
1	4751009	1.50 GPH Nozzle, Model 7230/8430	1
2	NO NUMBER	#10-24 x 5/16" Slotted Hex Head bolt <i>(not sold as repair part)</i>	0
3	4751224	Hold Down	1
4	4751226	Electrode and Buss Bar Assembly	1
5	4751227	Buss Bar ONLY	1
6	NO NUMBER	Flame Lock Assembly <i>(not sold as repair part)</i>	0